



Tavor X95 Cocking Bar and Barrel Band Install

1. Please follow the steps in your Tavor X95 manual to remove the recoil mechanism, the hand grip, the foregrip, cocking bar, barrel-rail group and remove your top rail.
2. Remove the flash suppressor by using two 19mm open wrenches.



3. Remove Teflon sleeve by using your finger to spread it open and push off.

- Warning: too much force can damage the sleeve.

4. Slide barrel band onto the end of the barrel in the groove. Ensure the barrel band is installed in the direction shown.



5. Use a hammer to insert pin into the barrel band.

- Warning: You must make sure the barrel band stays in the groove or you can damage the barrel. If the pin seems stuck it may not be in the groove.

Complete install for barrel band:

Note: the barrel band must be installed in this direction.



6. Reinstall the Teflon sleeve and ensure it is in the groove.

7. Follow the instructions in the manual to reassemble the X95.

8. When installing the new cocking rod the barrel band can rotate so the bar can slide past. Make sure you slide the band back before installing the foregrip.

- When installing the foregrip and hand grip screws use blue Lockite.

