

UZI® Pro

Buttstock Instillation

NFA Warning:

Please note installation of a buttstock will change your Uzi Pro to a short barreled rifle (SBR) subject to all the requirements of the National Firearms Act (NFA) for SBR's.

It is your responsibility to ensure you remain in compliance with all local, state and federal laws along with all NFA rules/regulations.

REMOVING THE BASE COVER

- ▶ Remove the UZI Pro base cover roll pins with a 2.5 mm punch and hammer
- ▶ Slide the base cover up to remove it



ATTACHING THE BUTTSTOCK

- ▶ Slide the buttstock down onto the UZI Pro
- ▶ Insert roll pins and hammer into the buttstock until roll pins are level with the buttstock
- ▶ Use a 2.5 mm punch and hammer to recess the roll pins

