

Magazine Catch Removal and Installation for the Tavor® SAR

Tools needed:

2 mm Punch
Hammer
Pliers

1. Tap pin holding the magazine catch from above the catch until comes half way through the bottom.



2. Grab the pin with a pair of pliers and pull it out.



Magazine Catch Removal and Installation for the Tavor® SAR

3. Remove magazine catch and spring. Place magazine release spring on new magazine catch. Make sure the long end is inside the catch and the curved end is outside.



4. Place new magazine release into the Tavor® and hold down the spring with one hand while hammering the pin with the other. The pin must be inserted with the pointed tip first.



5. At the half way point the pin will stop inserting. Push down on the magazine release spring to line the pin up correctly then hammer the pin in until it is flush with the body of the Tavor®.

