



**Tavor® 5.56 NATO/300 BLK
Single/Double Ejector
Bolt Parts Kit**

Contents:

- Firing Pin
- Firing Pin Spring
- Bolt Guide Pin
- Extractor Spring
- Securing Pin
- Extractor
- Extractor Pivot
- Ejector x 2
- Ejector Spring x 3
- Ejector Spring Guide x 3



Please Note:


The removal and installation of these parts should be completed by a certified gunsmith.

Distributed by

IWI US, Inc. 1441 Stoneridge Dr. Middletown, PA 17057

Item No. TP0212

Made in Israel

 Warning: Cancer and Reproductive Harm -
www.P65Warnings.ca.gov

The Tavor Single/Double Ejector Bolt Parts Kit Contains:

Single and Double Eject Bolt Parts:

- 00.704.3002 – Bolt-Guiding Pin
- 00.704.3001 – Firing Pin
- 00.798.3009 – Firing Pin Spring
- 00.704.3102 – Extractor
- 00.704.3106 – Extractor Pivot
- 00.704.3108A – Extractor Spring
- 00.704.3107 – Ejector Securing Pin
- 00.704.3103 – Ejector x 2

Use one ejector for single ejector bolts and two for double ejector bolts.

Single Eject Bolt Parts:

- 00.704.3104 – Ejector Spring (approx. 1.9")
- 00.704.3105 – Ejector Spring Guide (approx. 1.5")

Double Eject Bolt Parts:

- 02.705.3104 – Ejector Spring x 2 (approx. 1.2")
- 02.705.3105 – Ejector Spring Guide x 2 (approx. .8")

Please compare the bolt with your bolt on the next page to determine if you have a single eject or double eject bolt before installation.

Please compare your Tavor bolt to the pictures below:



For your Tavor SAR – Please see the current manual [here](#).
Please follow the instructions on this Tavor SAR manual in
Section 14.1.4 – Recoil Mechanism
Then follow the instruction in your Tavor SAR manual in
Section 14.2.1.1 – Gas-Operated Recoil Mechanism

For your Tavor X95 – Please see the current manual [here](#).
Please follow the instructions in your Tavor X95 manual in
Section 14.1.4 – Recoil Mechanism
Then follow the instruction in your Tavor X95 manual in
Section 14.2.1.1 – Gas-Operated Recoil Mechanism